


**WARNING:** This guide is provided for educational purposes only and is provided as-is. Your PSU model may be different, use this information at your own risk.



## Macintosh LC III Power Supply (USA version by ASTEC)

### Should be replaced:

- Two: 120uf @ 10V ●
- Two: 220uf @ 10V ●
- One: 1200uf @ 16V ●
- One: 1000uf @ 10V ●
- One: 470uf @ 16V ●

### Should not need replacing: One: 180uf @ 400V ●

- One: 47uf @ 25V ●

For a full capacitor parts list and details visit: [www.Mac84.net/guides](http://www.Mac84.net/guides)